



Tern Overland

Engineered for Endurance

If condensation is forming between the panes of your Arctic Tern Awning window, that would indicate the need to control moisture levels inside the camper, something that can be very challenging. Propane heat, showers and general high humidity are some of the main contributors. Here's a link to an article with tips for controlling moisture:

<https://ternoverland.com/blog/how-to-tackle-moisture-and-condensation-in-your-camper/>

Once humidity levels have dropped, the condensation should dry out on its own.

The Arctic Tern windows have atmospheric pressure balancing vents on the inside of the window, obscured by the window struts. Below is a photo showing their locations:



The drying process can be expedited by temporarily removing the rubber restriction plugs located in those vent holes. Please let us know if you have any questions.