



How do I reduce the rattling of my window blind & screen, or correct retraction issues?

If you're experiencing rattling or insufficient retraction with your window blind & screen assembly, it may benefit from an increase in spring tension. Over time, the spring tension may decrease, requiring an adjustment. Below is a link to a video that describes the process of re-tensioning your blind & screen:

<https://youtu.be/UdB7zYeThmY>

Below is a chart showing the spring preload specs for all window sizes. You can increase the number of turns specified by one or two turns to see if that helps with the rattling or retraction issue.

Window	# of turns for blind	# of turns for screen
300x500	3	5
300x700	4	6
300x1100		
450x500	4	5
450x610	4	6
450x900	5	7
450x1100	6	8
500x300	2	2
550x700	5	7
550x900	5	7
550x1100	6	8

If you have questions, we're here to help. Please reach out to us using the contact information at the link below:

<https://ternoverland.com/contact-us>